



iPad Quick Start Guide (Kindergarten - Grade 2)

① Step One...Please Do This First



Plug your iPad charger into the wall and the other end into the device. Depending on your device's current battery level, **your device may take 2 hours of charging time in order to turn on**. Once on, it may take **a few hours to fully charge**. To turn the iPad on, press and hold the Sleep/Wake button until the Apple logo appears. It may take a moment to turn on completely.

② Connect to the Internet (WiFi)

1. Locate and tap the "Settings" icon . (Figure A)
2. Tap the Wi-Fi icon from the left menu bar. (Figure B #1)
3. Verify the Wi-Fi button is toggled "on". (Figure B #2)
4. Choose your family's WiFi network and type a password if requested. If you don't know your WiFi password, it's sometimes written on the bottom of the access device your Internet Service Provider gave to you. (Figure B #3)




Figure A




Figure B

③ Now, Let's Connect.

Click the Home button to return to the main screen, then, tap the "Start Here" (Figure C) icon in order to connect to our Web filter. This will open the iPad Start Here page (Figure D) on the district website. Once you've loaded this page from your school district iPad, our web filter will work silently in the background to provide your student with the correct access to online resources.

In the future, if you encounter any issues accessing online resources, you can tap the same "Start Here" web clip located on your iPad to authenticate your device at home.

Once the page loads, you can now exit this website, push the iPad's home button, and progress to Seesaw, Clever, or another application/website as directed by your teacher.



Figure C




Figure D

④ Technology Support for Your District Issued iPad

On our Distance Learning Technology Page you will find the following resources:

- **Student Logins**
Students can only login to learning websites and apps using their District issued account. Your student's username begins with their last name, first three letters of their first name, and the first letter of their middle name, followed by @wssd.bz. **(Example:** John Charles Smith = smithjohc@wssd.bz). *This is the same account used to access their Google Drive (Cloud-based storage), Seesaw, and Clever.*
 - **What if my student doesn't remember their password?** Your child's account information can be found in **PowerSchool** under the **Technology Information** section.
- **Answers to Frequently Asked Questions About Devices**
We've compiled our most commonly asked questions and have answered them for you in the FAQs section.
- **Instructional Technology Help Center**
Want to learn more about your device, Seesaw or Schoology? Our District Instructional Technology Advisors have produced videos and resources to assist families in using SeeSaw, Schoology, iPads, Chromebooks, and more. This information is linked for you in this section.
- **Device Support**
Having an issue with your District issued iPad or charger? Our Technology Department is here to help! Please visit the Tech Help Center link below for troubleshooting resources and who to see for assistance.
Note, if you're having an issue with a specific application, assignment, or link please reach out to your teacher for help.
- **Caring for Your Device**
Unsure how to clean your iPad? Cleaning instructions and helpful tips are posted in this section for students and parents.

To access these resources, please visit: <https://www.wssd.k12.pa.us/TechHelpCenter.aspx>